RPN-.VFT-A400

monitoring relays



Output circuit - contact data

· Multifunctions monitoring relays

(AC voltage monitoring in 3-phase network - 3(N)~ 400/230 V)

- Monitoring of phase failure, asymmetry, phase sequence
- Histeresis mode Adjustment of tripping delay
- Cadmium free contacts 1 CO and 2 CO AC input voltages
- Cover modular, width 17,5 mm
- Direct mounting on 35 mm rail mount acc. to EN 60715
- Compliance with standard EN 50178
- Recognitions, certifications, directives: RoHS, CE [II] 24

Output circuit - contact uata	· · · · · · · · · · · · · · · · · · ·		
Number and type of contacts	1 CO 2 CO		
Contact material	AgSnO ₂		
Max. switching voltage	300 V AC		
Rated load AC	1 12 A / 250 V AC 6 A / 250 V AC		
DC	1 12 A / 24 V DC 6 A / 24 V DC		
DC	1 0,3 A / 250 V DC 0,1 A / 250 V DC		
Rated current	12 A / 250 V AC 6 A / 250 V AC		
Max. breaking capacity AC	1 3 000 VA 1 500 VA		
Min. breaking capacity	1 W 10 mA		
Contact resistance	≤ 100 mΩ		
Max. operating frequency			
at rated load AC	1 600 cycles/hour		
Input circuit			
Supply voltage A	C = monitoring voltage		
Rated voltage 50/60 Hz A			
Must release voltage	$AC: \ge 0,2 U_n$		
Operating range of supply voltage	AC: \geq 0,2 On when supplied from at least two phases: 0,71,15 Un		
oporating range of supply voltage	when supplied from single phase: $0,851,15$ U _n		
Rated power consumption	1,2 W		
Range of supply frequency A			
Measuring circuit 0			
measured value	electrical voltage, RMS value, 50 Hz		
	3(N)~, sinus, 4863 Hz		
measuring inputs	= supply voltage AC: 3(N)~ 400/230 V		
measuring terminals	(N)-L1-L2-L3		
measuring range	0,71,15 Un		
overload capacity	≥ 1,2 Un		
hysteresis H	5 V		
• switching thresholds for single phase	ERROR: ≤ 175 V AC		
	OK: > 175 V AC		
	OK (when returning after an error): ≥ 180 V AC		
switching thresholds for asymmetry	smooth adjustment:		
	ERROR: > 580 V AC		
	$OK \le 580 V AC$		
	OK (when returning after an error): ≤ 0…75 V AC		
• switching thresholds for phase sequence	OK: correct sequence of phase connection to the terminals		
J F	ERROR: phase connection to terminals other than OK status		
Insulation according to EN 60664-1	,		
Insulation rated voltage	400 V AC		
Rated surge voltage Overvoltage category	4 000 V 1,2 / 50 μs III		
Insulation pollution degree	2		
Flammability class			
Dielectric strength	V-0 for modular cover, UL 94		
input - output	4 000 V AC type of insulation: basic		
contact clearance	1 000 V AC type of clearance: micro-disconnection		

0 The measuring circuit is not galvanically insulated from the relay supply circuit.

RPN-.VFT-A400 monitoring relays

General data			
Electrical life • resistive AC1	> 0,5 x 10 ⁵ 12 A, 6 A, 250 V AC		
Mechanical life (cycles)	> 3 x 10 ⁷		
Dimensions (L x W x H)	90 ❷ x 17,5 x 64,6 mm		
Weight	contact 1 CO: 72 g contacts 2 CO: 75 g		
Ambient temperature • storage	-40+70 °C		
(non-condensation and/or icing) • operating	-20+60 °C		
Cover protection category	IP 20 EN 60529		
Relative humidity	up to 85%		
Shock resistance	15 g		
Vibration resistance	0,35 mm DA 1055 Hz		
Meassuring circuit data o			
Functions	LOST D - phase failure monitoring		
	ASYM D - asymmetry monitoring		
	SEQ D - phase sequence monitoring		
	histeresis mode		
Ranges of asymmetry	smooth adjustment: OFF - permanent switching off;		
	580 V AC		
Time ranges of tripping delay	step adjustment: OFF - permanent switching off;		
	(1 s; 2 s ❸); 3 s; 4 s; 5 s; 6 s; 7 s; 8 s; 9 s		
Base accuracy	voltage measurement: ± 5% ④		
Accuracy of asymmetry settings	threshold limits: ± 10% 🛛		
Accuracy of delay time settings	threshold limits: ± 5% ❺ ❸		
Values affecting the timing adjustment			
• temperature	± 0,05% / °C		
supply voltage	± 0,01% / V		
Recovery time	200 ms		
LED indicator ③	two-colour LEDs (green/red) LOST+ASYM, SEQ:		
	indication of supply voltage U, error, tripping delay		
	yellow LED R - output relay status		

The measuring circuit is not galvanically insulated from the relay supply circuit.
Length with 35 mm rail catches: 98,8 mm.
For initial ranges (1 s; 2 s) setting accuracy is smaller than the given ones in technical parameters (significant influence of the operational relay operating time, processor start-time, and the moment of supply switching as referred to the AC supply course).
Calculated from the final range values, for the setting direction from minimum to maximum.
LeD indication - see "Additional functions", page 3.

Dimensions



Functions

LOST D - Phase failure monitoring (with delayed disconnection of contact R).



If the voltage at all phases will exceed 175 V and no error condition occurred earlier, then the operational relay R is switched on. If voltage at one of the three phases, L1, L2, L3 falls to a value of 175 V, then after applying a setpoint delay time, the R contact is switched off. The operational relay R will be switched back on when the voltage value at the given phase rises to 180 V. A rapid phase loss is treated as a phase sequence error and no delay is then applied.

ASYM D - Asymmetry monitoring (with delayed disconnection of contact R).



The operational relay R switches to the off position when the asymmetry exceeds the setpoint value (diagram: switching threshold of asymmetry error 60 V). The asymmetry caused by the return voltage of the receiver (e.g. a motor that still operates in only two phases) does not disconnect.

Additional functions

LEDs: two-colour (green/red) LOST+ASYM, SEQ - are lit permanently or flashes at 500 ms period where it is lit for 50% of the time, and off for 50% of the time. Yellow R is lit permanently.

SEQ D - Phase sequence monitoring (without delay for disconnection of contact R).

If all the phases are connected to the terminals in the correct sequence (L1->L1, L2->L2, L3->L3) or in a consecutive sequence, then the operational relay R switches on. When the phase sequence changes, the operational relay R is immediately switched off.

Allowed connections combinations phases with terminal:

Terminal	Phase		
L1 ->	L1		
L2 ->	L2		
L3 ->	L3		
L1 ->	L2		
L2 ->	L3		
L3 ->	L1		
L1 ->	L3		
L2 ->	L1		
L3 ->	L2		

L1: misalignment phase 0°

L2: misalignment phase $2\pi/3=120^{\circ}$

L3: misalignment phase $4\pi/3=240^{\circ}$

L1, L2, L3 - phase supply voltages; R - output state of the relay; T - delay time; t - time axis

Adjustment of the set values: the values of range of asymmetry and tripping delay are read in the course of the relay's operation. The set values may be modified at any moment.

 $\pmb{\text{Supply}}:$ the relay may be supplied with AC voltage 48...63 Hz of 161...264,5 V.

LED indication	LOST+ASYM 🙏	SEQ 🗘	R
green lights up all the time	power supply and asymmetry are correct	correct phase sequence	-
red lights up all the time	ERROR power supply or asymmetry	ERROR phase sequence	-
red flashes	ERROR power supply or asymmetry @	-	-
yellow does not light up	-	-	contact R disconnected
yellow lights up all the time	-	-	contact R connected

Ø Measurement of the tripping delay time (disconnection of contact R) after has occurred a phase failure or asymmetry error.

Mounting

Relays **RPN-.VFT-A400** are designed for direct mounting on 35 mm rail mount acc. to EN 60715. Operational position - any. **Connections:** max. cross section of the cables: 1 x 2,5 mm² (1 x 14 AWG), stripping length: 6,5 mm, max. tightening moment for the terminal: 0,5 Nm.



Two catches: easy mounting on 35 mm rail, firm hold (top and bottom).



Mounting wires in clamps: universal screw (cross-recessed or slotted head).

RPN-.VFT-A400 monitoring relays

Front panel description



S Requires terminal (N) connection to the neutral wire.

Ordering codes



Examples of ordering codes:

RPN-1VFT-A400 monitoring relay **RPN-1VFT-A400**, multifunction (relay perform 3 functions), cover - modular, width 17,5 mm, one changeover contact, contact material AgSnO₂, rated input voltage = monitoring 3(N)~ 400/230 V AC 50/60 Hz

RPN-2VFT-A400 monitoring relay **RPN-2VFT-A400**, multifunction (relay perform 3 functions), cover - modular, width 17,5 mm, two changeover contacts, contact material AgSnO₂, rated input voltage = monitoring 3(N)~ 400/230 V AC 50/60 Hz

PRECAUTIONS:

1. Ensure that the parameters of the product described in its specification provide a safety margin for the appropriate operation of the device or system and never use the product in circumstances which exceed the parameters of the product. 2. Never touch any live parts of the device. 3. Ensure that the product has been connected correctly. An incorrect connection may cause malfunction, excessive heating or risk of fire. 4. In case of any risk of any serious material loss or death or injuries of humans or animals, the devices or systems shall be designed so to equip them with double safety system to guarantee their reliable operation.